






















2500



All the space under the horizontal bypass - including diverter is used for: installation, inspection and maintenance of the air tube transport equipment.



In the interest of continuous improvement and upgrade of our products Hörtig reserves the right to change the technical specifications at any time, without prior notice.

All the space in front of the vertical bypass is used for:
installation, inspection and maintenance of the air tube transport equipment.